

460L frost free top mount in white finish. Featuring FlexStor door bin storage solutions, Spillsafe glass shelves and easy access pocket handles.

RRP AUS \$1,199.00

Product Details

FEATURES

FlexStor™ door bin storage system	Full-width crisper	Spillsafe™ glass shelves	Pocket handle
LED lighting	Separate temperature controls for fridge and freezer	Fridge door alarm	Full-width freezer door bin
Multi-flow Air Delivery	Ice cube tray	Frost free	Rear rollers

BENEFITS

Convenient storage solution with FlexStor Easily change the configuration of your fridge door to suit you.	Fill your fridge the way you want to The large fridge interior is big enough for even the largest items
Easy to clean With handy features like SpillSafe glass shelves, easy to clean liner & fewer nooks and crannies makes the fridge a breeze to clean.	Easy access The pocket handles allow easy access and make cleaning a breeze.

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Additional domestic warranty for the sealed refrigeration system only (yrs)	3
Refrigerator Type	top mount
Exterior door finish	White
Handle design	integrated
Fridge door opening	right
Cooling system	frost free
Freezer door opening	right
Refrigerant	R600a

DIMENSIONS

Total height (mm)	1718
Cabinet height (mm)	1705
Total width (mm)	699
Cabinet width (mm)	693
Total depth (mm)	730
Cabinet depth (mm)	641
Depth door open 90degree (mm)	1360
Food Compartment Capacity AS/NZS IEC 62552-3 (L)	329
Freezer Compartment Capacity AS/NZS IEC 62552-3 (L)	102
Total Capacity AS/NZS IEC 62552-3 (L)	341
Food compartment capacity (gross in litres)	431
Freezer compartment capacity (gross in litres)	119

ENERGY

Energy Star Rating AS/NZS IEC 62552-3	3.5
Energy Consumption AS/NZS IEC 62552-3 (kWh/year)	366
Energy Star Rating AS/NZS 4474.2:2009	3.5
Energy consumption AS/NZS 4474.2:2009 (kWh/yr)	385

FOOD COMPARTMENT

SHELVING

Shelf material	glass
Type of shelf	spill safe shelf

DIMENSIONS

Total Gross Capacity (L)	460
Food compartment capacity (net in litres)	327
Total Net Capacity (L)	426

REFRIGERATOR SYSTEM

Controls	manual
Controls location	internal
Door alarm	fridge

CRISPERS

Crisper lid/shelf	glass
Crispers Runner system	suspended
Full width crisper	1

LIGHTING

Main light	LED
------------	-----

OTHER PROPERTIES

Seals	removable
-------	-----------

SHELVING

Shelving	glass shelf
Type of shelf	spill safe shelf
Number of shelves	1

FOOD COMPARTMENT DOOR

BINS

Deep bottle bin	1
Shallow bin	1

FREEZER COMPARTMENT

ICE FACILITY


Ice cube tray	1
---------------	---

FREEZER DOOR

INTERNAL

Freezer door bins - full width	1
Seals	removable

Dimensions



Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz