

280 litre frost free top mount with easy clean vibrant silver finish

RRP AUS \$869.00

Product Details

FEATURES

Door alarm	Multi-flow air delivery system	Chiller drawer	Adjustable Spillsafe™ glass shelves Catch spills and clean with ease
Full-width humidity controlled crisper bin	Frost free	Twist ice and serve (removable) make ice with ease and cool drinks at a twist	FlexStor™ door bin storage system
Adjustable levelling feet (front)	R600a refrigerant better for the environment	Deodoriser Absorb pungent food smells to keep flavours fresh and distinct.	

BENEFITS

Adjustable solutions with FlexStor™ As your family changes and grows, so do the requirements of your fridge. With FlexStor™ you enjoy the convenience of being able to easily change the configuration, whatever your needs. Adjust the height and position of the door bins to fit in large and smaller items and arrange your fridge your way.	Twist ice & Serve Twist ice and serve with ice caddy provides you with easy access to more ice, more often
Humidity controlled crisper Offers the perfect environment for preserving fruit and vegetables, as well as having a removable crisper front for easy cleaning	Easy to clean with Spillsafe glass shelves Spillsafe glass shelves improve visibility and isolate leaks. Preventing up to 1 litre of spills from dripping onto shelves below

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	2
Refrigerator Type	top mount
Exterior door finish	Pacific silver
Fridge door opening	reversible (with optional door kit)
Cooling system	frost free
Refrigerant	R600a

ENERGY

Energy Star Rating New	2.5
------------------------	-----

DIMENSIONS

Total height (mm)	1605
Cabinet height (mm)	1590
Total width (mm)	540
Cabinet width (mm)	540
Total depth (mm)	615
Cabinet depth (mm)	540
Depth door open 90degree (mm)	1108
Air space above cabinet (mm)	90
Food compartment capacity (gross in litres)	198
Total Gross Capacity (L)	280

REFRIGERATOR SYSTEM

Controls	manual
----------	--------

ENERGY

Energy consumption (KWhr/yr)	385
------------------------------	-----

REFRIGERATOR SYSTEM

Controls location	internal
Control functions	quick freeze function
Door alarm	fridge and freezer

FOOD COMPARTMENT

DELI-COMPARTMENT

Full width compartment	1
------------------------	---

SHELVING

Shelf material	glass
----------------	-------

CRISPERS

Crisper lid/shelf	plastic
Crispers Runner system	floor
Full width crisper	1
Crisper features	humidity controlled

LIGHTING

Main light	incandescent
------------	--------------

OTHER PROPERTIES

Other Properties-FOOD COMPARTMENT	Deodoriser
-----------------------------------	------------

FOOD COMPARTMENT DOOR

BINS

Deep bottle bin	1
-----------------	---

Shallow bin	1
-------------	---

FREEZER COMPARTMENT

ICE FACILITY

Twist ice and serve	2
---------------------	---

FREEZER DOOR

INTERNAL

Freezer door bins - full width	2
--------------------------------	---

SHELVING

Shelving	plastic shelf
----------	---------------

Number of shelves	1
-------------------	---

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz