

14cm built-in warming drawer with variable temperature control, versatile functionality and push to open with soft closing drawer. Designed to suit Electrolux 500 and 600 series 60cm built-in ovens

Product Details

FEATURES

Adjustable temperature between 40-80C

Push to open, soft closing drawer

Fan forced heating

Quick set function

Full drawer extension

Electronic touch controls

BENEFITS

MORE THAN JUST A PLATE WARMER

This warming drawer can do much more than just keep plates and food warm. With multiple temperature settings you also have access to an array of helpful functions. Choose to defrost frozen food, prove dough, ferment yoghurt, or even dehydrate fruit, all in one versatile appliance.

EFFORTLESS PLATE WARMING

The push-to-open, soft-closing drawer with full extension makes it so simple to warm your plates and dishes, especially when your hands are full. For added safety, the warming drawer stops heating automatically when open.

MAKE DRAWER-DRIED FRUITS

Dehydrating fruits in your warming drawer at between 40-60C is a deliciously simple way to preserve fruits such as apples, bananas, oranges and pears without the need for a dedicated dehydrating appliance. The dried fruit can be stored for long periods at room temperature to be used as garnish, infused in tea or enjoyed as tasty, healthy snacks.

LOW TEMPERATURE COOKING

Slow cooking at approximately 80 degrees celsius for 3-4 hours produces tasty, tender meat that falls off the bone with a touch. If you love baking your own bread, the ovens very low temperature program of 25-30 degrees celsius is also ideal for allowing dough to rise.

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	3
Type	built-in

EXTERIOR

Exterior Finish	Black glass
Push to open drawer system	yes
Soft close door	Yes

DIMENSIONS

PRODUCT

Total height (mm)	141
Total width (mm)	595

FEATURES

Number of place settings	6
Features	Cups & Glass warming (40d °C),Plate Warming (60d °C),Fan air circulation,On/Off LED,Anti-slip mat,Adjustable temperature range 40-80°C,Operating indicator light ,Thermal cut out,Overheat protection

SPECIFICATIONS

Power	Plug
Maximum Power Rating (W)	1000

FLUSH

Cut out height (mm)	143
Cut out width (mm)	600

Total depth (mm)	541
------------------	-----

Cut out depth (mm)	570
--------------------	-----

SHIPPING

Shipping Volume (m3)	0.10
----------------------	------

Shipping Weight (Kg)	21.0
----------------------	------

Pack dimensions height	210
------------------------	-----

Pack dimension width	705
----------------------	-----

Pack dimension depth	675
----------------------	-----

STUFFING QUANTITIES

20ft	264
------	-----

40ft	561
------	-----

40ft HC	612
---------	-----

Dimensions

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz